



Virginia Department of Environmental Quality
Small Business Assistance Program
PO Box 1105, Richmond, VA 23218-1105
Telephone: 804.698.4394 or Toll-Free: 800.592.5482 ext. 4394 (in-state only)

Online: www.deq.virginia.gov/osba/





COMMONWEALTH of VIRGINIA

DEPARTMENT OF ENVIRONMENTAL QUALITY

L. Preston Bryant, Jr. Secretary of Natural Resources

Street address: 629 East Main Street, Richmond, Virginia 23219

Mailing address: P.O. Box 1105, Richmond, Virginia 23218-1105

Fax (804) 698-4500 TDD (804) 698-4021

www.deg.virginia.gov

David K. Paylor Director

(804) 698-4000 1-800-592-5482

Dear Dry Cleaning Owner:

The Office of Small Business Assistance would like to wish you a very joyous holiday season and a prosperous New Year. In keeping with our mission and compact with the dry cleaners across the Commonwealth to help them understand and implement new environmental regulations, we are pleased to introduce you to the newly reformatted **2008 Compliance Calendar for Dry Cleaners**. As you will see it has a new look, a new organization and most importantly additional information to help you comply with the recent additions to the Federal EPA Dry Cleaning Rule.

There are couple of items that we want you to know: first, Virginia has adopted the new Federal rule as a part of its regulations; and second, we want to emphasize that the new rule contains new requirements that you are responsible for that previously were not a part of your day-to-day compliance with the original rule. The new requirements are included in the calendar guidance materials.

We encourage you to use the calendar to keep the records for your facility. The calendar contains all of the recordkeeping elements that are necessary for you to prove your compliance with State and Federal rules. Remember if you use this calendar as your annual compliance record, you must be keep it on-site for 5 years. You should only use one calendar for one machine. If you have two machines you should maintain two calendar. Please encourage your competitors, especially new dry cleaners, to use the calendar. Tell them how they can get in touch with the Office of Small Business Assistance to obtain their own calendar.

One area that continues to create some confusion is when you should notify DEQ of a change in information and what kind of change. You must notify your regional DEQ office, in writing, within 30 days of making a change to any of the following: business name, location, store contact person, phone number, dry cleaning machine equipment, or sale of the business (please provide new owner's name and contact information). Make sure you reference your DEQ Air Registration Number.

I would like to congratulate you on your efforts to maintain your compliance and on your efforts to improve your workplace for your employees and the environment of Virginia. Together, as we have for the last 14 years, we can continue to make progress. If you have any questions, please call me at 1-800-592-5482 ext. 4394, or at (804) 698-4394. It has been our pleasure in the Office of Small Business Assistance to serve you.

Sincerely,

Richard G. Rasmussen

Director

Office of Small Business Assistance

	Page
Regulatory Overview	1
Calendar Instructions	2-4
Monthly Charts and Calendars for January 2008 - December 2008	5-28
Status of Compliance Notification Form provided between July chart and calendar	
Order Form and Survey provided between September chart and calendar	
Definitions	29-30
Determining if the Regulations Affect Your Facility	31
Store Classification and Requirements	32
Registration and Permits	33
Additional Requirements	33
Co-Residential Requirements	34
DEQ Regional Map	35
Helpful Contacts and Resources	
Hazardous Waste Requirements	37
Waste Generation/Treatment Log	38
Future Rule Changes	39

Regulatory Overview

The Clean Air Act of 1990 directed the United States Environmental Protection Agency (EPA) to regulate the emissions of 189 chemical compounds designated as Hazardous Air Pollutants (HAPs). The Perchloroethylene that you use in your dry cleaning machine, also known as "perc," is one of the chemicals. Perc is the most commonly used chemical cleaning solvent used by dry cleaners.

In September 1993, EPA issued national regulations to control air emissions of perc from dry cleaners. In 1999, Virginia passed its own regulation for perc dry cleaning operations. Virginia adopted the Federal Regulation as their own. These regulations created operational standards and control technology requirements to reduce perc air emissions from dry cleaning operations.

More recently, EPA was required to strengthen the existing regulations due to potential health risks caused by perc. Perc is considered to be a potential cause of cancer. Congress and EPA mandated that the health hazard caused by perc be regulated to limit exposure to the chemical. On July 27, 2006, EPA published additional new regulations for perc drycleaners. This regulation revised the 1993 rule. The 2006 rule requires additional emission controls for new drycleaner shops that have erected or installed new or used dry cleaning machine systems after December 21, 2005. The new rule also created special requirements for dry cleaning shops that are located in buildings containing residences, "co-residential." Fortunately, Virginia has very few of co-residential dry cleaning shops.

This calendar will help you keep accurate records for both the State and Federal reporting requirements. It is an effective tool to maintain your records and your compliance with both the old and revised Virginia and Federal Perchloroethylene Dry Cleaner Regulations. Remember the calendar is your Annual Record of Compliance. You must keep these (records) calendars for a period of 5 years. Also, remember that it is your responsibility to let us know if your address changes, or if the ownership of your shop changes.

You must have a copy of the operations manual for your machine, your refrigeration condenser and carbon adsorber on-site at all times.

Please take advantage of this resource and all the resources provided in the calendar. Working together we can make a difference in Virginia's environment. If you have any questions, please contact Richard Rasmussen, Director of the DEQ Office of Small Business Assistance, at 1-800-592-5482 ext. 4394, or at (804) 698-4394.

Regulatory Citations

Virginia Requirements: 9 VAC 5-60-100, Subpart M- Designated Emission Standards for Perchloroethylene Dry Cleaning Facilities Federal EPA Requirements: 40 CFR 63.320 through 40 CFR 63.325, Subpart M--Perchloroethylene Dry Cleaning Facilities

Calendar Instructions

General Instructions

- This calendar contains all the record-keeping elements that you need to comply with the Sate and Federal rules. Please fasten the calendar directly to your perc dry cleaning machine.
- Complete the logs and charts for each month to fulfill your recordkeeping requirements. Remember the calendar is your annual record of compliance you must keep the calendar for a period of 5 years.
- Read definitions and regulatory requirements that begin on page 29.

Weekly Equipment Inspections

- If you buy 140 gallons or more of perc per year, you must check your machine weekly for leaks and record the results.
- If you buy less than 140 gallons of perc per year, you must conduct and record leak inspections at least every other week.
- Record the results of the inspections on the calendar. If leaks are found, or pressures, or temperatures are not correct, your machine must be repaired within 24 hours, if replacement parts are on-site. See below instructions for Repair Log.
- Circle the method of inspection "P" for perceptible (feel, see or smell), or "D" for using the Detector. Also when you use the Hydrocarbon Detector for your monthly leak check you do not have to do the perceptible leak check for the that week. You may use the Hydrocarbon Detector for each of your weekly checks, if you prefer this method.
- Beginning on July 28, 2008, you must inspect your machine and its components on a monthly basis using a "Halogenated Hydrocarbon Detector," if your machine was installed prior to July 27, 2006. If your machine was installed on or after July 27, 2006, you must begin using the Halogenated Hydrocarbon Detector from the date of installation of your machine.
- How to Use the Detector: Make sure the batteries are good, and that the tip of the wand is clean and not contaminated with perc. Keep the tip 1" from the surface of the gaskets, connections, seals, etc., that you are inspecting and move it very slowly approximately 1" per second. Remember that you will have to do the testing during each of the cycles of the machine while components of the machine are being used: the wash cycle, the dry cycle and the distillation cycle. Read the directions for your detector to understand the identification of a leak, e.g. a rapid sound or rapid light pulse. A quantity of 25 ppm is now the definition of a "perc leak." If the detector registers a leak, the leak must be repaired according to the repair schedules.

Repair Log

If leaks are found, or pressures, or temperatures are not correct, your machine must be repaired within 24 hours, if replacement parts are on-site. In the Repair Log, please provide the inspection date and a description of the required repair; as well as the dates that the necessary part or parts were ordered, received and installed, and the date that the repair was completed. Parts must be ordered within 2 working days of leak detection and installed within 5 working days of receipt.

Repair Log — EXAMPLE 1				
Inspection Date and Description of Repair		Date Part Received	Date Part Installed	Date Repaired
1/4/08 door gasket leaking (no replacement parts onsite)	1/6/08	1/15/08	1/21/08	1/22/08

Repair Log — EXAMPLE 2				
Inspection Date and Description of Repair	Date Part Ordered	Date Part Received	Date Part Installed	Date Repaired
1/4/08 door gasket leaking (have replacement parts onsite)			1/4/08	1/5/08

Calendar Instructions continued

Refrigerated Condenser Monitoring Log

A. If your machine has pressure gauges:

- 1. Record the pressures of the high and low pressure gauges.
- 2. Indicate if the pressures are within the machine specifications by marking Y for yes, or N for no. If you circle N, your machine must be repaired.

B. If your machine does not have pressure gauges:

- 1. Record the outlet temperature of the refrigerated condenser prior to the end of the cool down cycle while the gas-vapor stream is still flowing through the condenser.
- 2. Indicate if the temperature less than or equal to 45°F (7.2°C). Circle Y for yes, or N for no. If you circle N, the machine must be repaired.

Refrigerated Condenser Monitoring Log								
Week	1	2	3	4	5			
If your machine has pressure gauges: Record pressures of high and low pressure gauges.								
Are pressure gauges within the ranges specified in the manual?	Y N	Y N	Y N	Y N	Y N			
If your machine does NOT have pressure gauges: Record refrigerated condenser outlet temperature.								
Is the temperature gauge ≤45°F?	Y N	YN	Y N	ΥN	ΥN			
If you are operating a transfer machine: Record inlet and outlet temperatures weekly.								
Calculate the difference (inlet - outlet)								
Is the difference $\geq 20^{\circ}F$	Y N	YN	Y N	ΥN	YN			

C. If you are still operating a Transfer System:

- 1. For the washer only, measure the inlet and outlet temperatures.
- 2. Calculate the difference between the temperatures (subtract the outlet temperature from the inlet).
- 3. Indicate if the difference is greater than or equal to 20°F. Circle Y for yes, or N for no. If N, the machine must be repaired.

Secondary Carbon Adsorber Monitoring

A. When a carbon adsorber is vented and is used on a machine installed before September 22, 1993:

- 1. Measure the perc concentration at the outlet vent of the carbon adsorber on the last machine cycle prior to the desorption of the carbon adsorber, or the replacement of the charcoal. You must use a colorimetric tube and the perc concentration must be less than or equal to 100 ppm with an accuracy of ± 25 ppm by volume.
- 2. Indicate whether the perc concentration is less than 100 ppm, by circling Y for yes, or N for no.
- 3. If the readings do not meet the required limits, desorb the carbon adsorber according to the machine manufacturers instructions and take the readings again during another cycle. If they still do not meet the required specification, the machine needs to be repaired.


B. When a non-vented carbon adsorber is used to pass the gas vapor stream through the adsorber prior to door being opened on a machine installed after Dec. 21, 2005:

- 1. Measure final perc concentration, by placing a colorimetric detector tube or a PCE gas analyzer into the open space above the articles of clothing at the rear of the dry cleaning machine drum immediately upon opening the door. The reading should be less than or equal to 300 ppm with an accuracy of ±75 ppm by volume.
- 2. Indicate whether the perc concentration is less than 300 ppm, by circling Y for yes, or N for no.
- 3. If the readings do not meet the required limits, desorb the carbon adsorber according to the machine manufacturers instructions and take the readings again during another cycle. If they still do not meet the required specification, the machine needs to be repaired.

Calendar Instructions continued

Perc Purchases Running Total

This chart must be completed on the first day of each month. Below is an example of how to complete the Perc Purchases Running Total chart.



If you have any questions, please contact Richard Rasmussen, Director of the DEQ Office of Small Business Assistance, at 1-800-592-5482 ext. 4394, or at (804) 698-4394.

Do you need additional copies of this calendar? You should have a calendar posted to **each** of your perc dry cleaning machines. To request additional copies, please contact Dana Brancolini by telephone at (804) 698-4115, or e-mail at drbrancolini@deq.virginia.gov.



January 2008

W	Weekly Equipment Inspections							
Are the components without leaks? Circle Y for yes, or N for no.								
	ethod: choose one. Circle P for touch, sight smell, or D for use of detector	P D	P D	P D	P D	P D		
	Week	1	2	3	4	5		
	Hose connections, unions, couplings & valves	ΥN	ΥN	YN	ΥN	YN		
<	Machine door gasket and seating	YN	YN	YN	YN	YN		
vas	Pumps	ΥN	ΥN	YN	ΥN	YN		
wash cycle	Button trap	Y N	YN	YN	ΥN	Y N		
ycl	Filter housings	Y N	YN	Y N	ΥN	YN		
P	Filter gaskets and seating	Y N	YN	Y N	ΥN	Y N		
	Solvent tanks	Y N	YN	Y N	YN	Y N		
	Deodorizing and aeration valves on dryers	Y N	ΥN	Y N	ΥN	YN		
₫	Air and exhaust ductwork	ΥN	ΥN	YN	ΥN	YN		
dry cycle	Heating and cooling coil doors	YN	YN	YN	YN	YN		
уc	Hose connections, unions, couplings & valves	YN	YN	YN	YN	YN		
ē	Water seperators	YN	YN	YN	ΥN	YN		
	Lint trap	YN	YN	YN	ΥN	YN		
di	Hose connections, unions, couplings & valves	YN	YN	YN	YN	YN		
stil	Water seperators	YN	YN	YN	ΥN	YN		
lati	Distillation unit	YN	YN	YN	ΥN	YN		
on,	Solvent tanks	Y N	YN	YN	ΥN	Y N		
distillation, misc	Muck coolers	ΥN	ΥN	YN	ΥN	YN		
İSC	Waste tanks and storage containers	YN	YN	YN	YN	YN		

Repair Log								
Inspection Date and Description of Repair	Date Part Ordered	Date Part Received	Date Part Installed	Date Repaired				

Week:	1	2	3	4	5
Date:					
Staff Initials:					

Refrigerated Condenser Monitoring Log								
Week	1	2	3	4	5			
If your machine has pressure gauges: Record pressures of high and low pressure gauges.								
Are pressure gauges within the ranges specified in the manual?	Y N	Y N	Y N	Y N	Y N			
If your machine does NOT have pressure gauges: Record refrigerated condenser outlet temperature.								
Is the temperature gauge ≤45°F?	YN	ΥN	YN	ΥN	Y N			
If you are operating a transfer machine: Record inlet and outlet temperatures weekly.								
Calculate the difference (inlet - outlet)								
Is the difference $\geq 20^{\circ} F$	ΥN	ΥN	ΥN	ΥN	YN			

Secondary Carbon Absorber Monitoring							
Week	1	2	3	4	5		
Is perc concentration less than 100 ppm? (for machines that vent to carbon adsorbers immediately upon machine door opening)	Y N	Y N	Y N	Y N	Y N		
Is perc concentration less than 300 ppm? (for machines that vent to carbon adsorbers prior to machine door opening)	ΥN	ΥN	Y N	ΥN	Y N		

Perc Purchases Running Total							
Total from	Last Month						
	erc Purchased ARY 2007	-					
Sul	ototal						
Purchase Date	Purchase Amount	12 Month Running Total					
	+						
	+						



January 2008

Sun	Mon	Tue	Wed	Thu	Fri	Sat
		1	2	3	4 Temp logged □ Inspect logged □	5
6	7	8	9	10	11 Temp logged Inspect logged	12
13	14	15	16	17	18 Temp logged □ Inspect logged □	19
20	21	22	23	24	25 Temp logged Inspect logged	26
27	28	29	30	31		

Virginia Department of Environmental Quality Small Business Assistance Program PO Box 1105 Richmond, VA 23218-1105

Toll-Free: 800.592.5482 ext. 4394 (in-state only) Telephone: 804.698.4394 Fax: 804.698.4264

osba@deq.virginia.gov



Beginning on July 28, 2008, you must inspect your machine and its components on a monthly basis using a "Halogenated Hydrocarbon Detector," if your machine was installed prior to July 27, 2006. If your machine was installed on or after July 27, 2006, you must begin using the Halogenated Hydrocarbon Detector from the date of installation of your machine.

Complete January 2008 chart in the Waste Generation/Treatment Log on page 38.

Good idea: Close and secure machine doors except during loading and unloading.





February 2008

W	Weekly Equipment Inspections							
Are the components without leaks? Circle Y for yes, or N for no.								
	ethod: choose one. Circle P for touch, sight smell, or D for use of detector	P D	P D	P D	P D	P D		
	Week	1	2	3	4	5		
	Hose connections, unions, couplings & valves	ΥN	ΥN	ΥN	ΥN	YN		
<	Machine door gasket and seating	YN	ΥN	YN	ΥN	YN		
vas	Pumps	ΥN	ΥN	ΥN	ΥN	YN		
h c	Button trap	Y N	ΥN	Y N	ΥN	Y N		
wash cycle	Filter housings	Y N	ΥN	YN	ΥN	YN		
æ	Filter gaskets and seating	YN	ΥN	ΥN	ΥN	YN		
	Solvent tanks	Y N	ΥN	YN	ΥN	Y N		
	Deodorizing and aeration valves on dryers	ΥN	ΥN	ΥN	ΥN	YN		
٩	Air and exhaust ductwork	YN	ΥN	ΥN	ΥN	YN		
dry o	Heating and cooling coil doors	YN	ΥN	ΥN	ΥN	YN		
cycle	Hose connections, unions, couplings & valves	Y N	ΥN	ΥN	ΥN	YN		
ē	Water seperators	YN	ΥN	ΥN	ΥN	YN		
	Lint trap	YN	ΥN	YN	ΥN	YN		
ď	Hose connections, unions, couplings & valves	Y N	ΥN	ΥN	ΥN	YN		
distillation,	Water seperators	ΥN	ΥN	ΥN	ΥN	YN		
lati	Distillation unit	YN	ΥN	YN	ΥN	YN		
on,	Solvent tanks	ΥN	ΥN	ΥN	ΥN	YN		
misc	Muck coolers	YN	ΥN	ΥN	ΥN	YN		
isc	Waste tanks and storage containers	Y N	ΥN	Y N	ΥN	Y N		

Repair Log				
Inspection Date and Description of Repair	Date Part Ordered	Date Part Received	Date Part Installed	Date Repaired

Week:	1	2	3	4	5
Date:					
Staff Initials:					

Refrigerated Condenser Monitoring Log						
Week	1	2	3	4	5	
If your machine has pressure gauges: Record pressures of high and low pressure gauges.						
Are pressure gauges within the ranges specified in the manual?	Y N	Y N	Y N	Y N	Y N	
If your machine does NOT have pressure gauges: Record refrigerated condenser outlet temperature.						
Is the temperature gauge ≤45°F?	Y N	ΥN	ΥN	ΥN	ΥN	
If you are operating a transfer machine: Record inlet and outlet temperatures weekly.						
Calculate the difference (inlet - outlet)						
Is the difference $\geq 20^{\circ} F$	Y N	ΥN	ΥN	ΥN	YN	

Secondary Carbon Absorber Monitoring						
Week	1	2	3	4	5	
Is perc concentration less than 100 ppm? (for machines that vent to carbon adsorbers immediately upon machine door opening)	Y N	Y N	Y N	Y N	Y N	
Is perc concentration less than 300 ppm? (for machines that vent to carbon adsorbers prior to machine door opening)	Y N	Y N	Y N	Y N	Y N	

Perc Purchas	Perc Purchases Running Total					
Total from	Last Month					
Subtract Perc Purchased FEBRUARY 2007		-				
Sul	ototal					
Purchase Date	Purchase Amount	12 Month Running Total				
	+					
	+					



February 2008

Sun	Mon	Tue	Wed	Thu	Fri	Sat
					1 Temp logged Inspect logged	2
3	4	5	6	7	8 Temp logged Inspect logged	9
10	11	12	13	14	15 Temp logged Inspect logged	16
17	18	19	20	21	22 Temp logged Inspect logged	23
24	25	26	27	28	29 Temp logged Inspect logged	

Virginia Department of Environmental Quality Small Business Assistance Program PO Box 1105 Richmond, VA 23218-1105

Toll-Free: 800.592.5482 ext. 4394 (in-state only) Telephone: 804.698.4394 Fax: 804.698.4264

osba@deq.virginia.gov



Complete February 2008 chart in the **Waste Generation/Treatment Log** on page 38.

Good idea: Drain cartridge filters in their housings for at least a 24-hour period.





March 2008

W	Weekly Equipment Inspections						
Are	Are the components without leaks? Circle Y for yes, or N for no.						
	ethod: choose one. Circle P for touch, sight smell, or D for use of detector	P D	P D	P D	P D	P D	
	Week	1	2	3	4	5	
	Hose connections, unions, couplings & valves	ΥN	ΥN	YN	ΥN	ΥN	
<	Machine door gasket and seating	YN	YN	YN	ΥN	YN	
vas	Pumps	ΥN	ΥN	YN	ΥN	ΥN	
wash cycle	Button trap	ΥN	ΥN	YN	ΥN	ΥN	
ycl	Filter housings	ΥN	ΥN	YN	ΥN	ΥN	
æ	Filter gaskets and seating	ΥN	YN	YN	ΥN	ΥN	
	Solvent tanks	ΥN	ΥN	YN	ΥN	ΥN	
	Deodorizing and aeration valves on dryers	ΥN	ΥN	YN	ΥN	ΥN	
٩	Air and exhaust ductwork	Y N	ΥN	YN	ΥN	ΥN	
dry cycle	Heating and cooling coil doors	Y N	ΥN	YN	ΥN	ΥN	
<u>ycl</u>	Hose connections, unions, couplings & valves	Y N	ΥN	Y N	ΥN	YN	
æ	Water seperators	Y N	ΥN	Y N	ΥN	ΥN	
	Lint trap	Y N	ΥN	Y N	ΥN	ΥN	
<u>di</u>	Hose connections, unions, couplings & valves	Y N	ΥN	Y N	ΥN	ΥN	
ŧ	Water seperators	Y N	ΥN	Y N	ΥN	ΥN	
distillation,	Distillation unit	Y N	ΥN	Y N	ΥN	ΥN	
on,	Solvent tanks	Y N	ΥN	Y N	ΥN	ΥN	
misc	Muck coolers	YN	Y N	YN	ΥN	ΥN	
SC	Waste tanks and storage containers	Y N	YN	Y N	YN	YN	

Repair Log				
Inspection Date and Description of Repair	Date Part Ordered	Date Part Received	Date Part Installed	Date Repaired

Week:	1	2	3	4	5
Date:					
Staff Initials:					

Refrigerated Condenser Monitoring Log						
Week	1	2	3	4	5	
If your machine has pressure gauges: Record pressures of high and low pressure gauges.						
Are pressure gauges within the ranges specified in the manual?	Y N	Y N	Y N	Y N	Y N	
If your machine does NOT have pressure gauges: Record refrigerated condenser outlet temperature.						
Is the temperature gauge ≤45°F?	ΥN	ΥN	Y N	ΥN	ΥN	
If you are operating a transfer machine: Record inlet and outlet temperatures weekly.						
Calculate the difference (inlet - outlet)						
Is the difference $\geq 20^{\circ} F$	YN	YN	Y N	YN	YN	

Secondary Carbon Absorber Monitoring						
Week	1	2	3	4	5	
Is perc concentration less than 100 ppm? (for machines that vent to carbon adsorbers immediately upon machine door opening)	Y N	Y N	Y N	Y N	Y N	
Is perc concentration less than 300 ppm? (for machines that vent to carbon adsorbers prior to machine door opening)	ΥN	ΥN	Y N	ΥN	Y N	

Perc Purchas	ses Running To	tal
Total from	Last Month	
Subtract Perc Purchased MARCH 2007		-
Sul	ototal	
Purchase Date	Purchase Amount	12 Month Running Total
	+	
	+	



March 2008

Sun	Mon	Tue	Wed	Thu	Fri	Sat
						1
2	3	4	5	6	7 Temp logged Inspect logged	8
9	10	11	12	13	14 Temp logged Inspect logged	15
16	17	18	19	20	21 Temp logged Inspect logged	22
23	24	25	26	27	28 Temp logged Inspect logged	29
30	31					

Virginia Department of Environmental Quality Small Business Assistance Program PO Box 1105 Richmond, VA 23218-1105

Toll-Free: 800.592.5482 ext. 4394 (in-state only) Telephone: 804.698.4394 Fax: 804.698.4264

osba@deq.virginia.gov







April 2008

W	eekly Equipment Inspections					
Are	e the components without leaks? Circle Y fo	r yes,	or N fo	r no.		
	ethod: choose one. Circle P for touch, sight smell, or D for use of detector	P D	P D	P D	P D	P D
	Week	1	2	3	4	5
	Hose connections, unions, couplings & valves	ΥN	ΥN	ΥN	ΥN	Y N
<	Machine door gasket and seating	YN	ΥN	YN	ΥN	Y N
vas	Pumps	ΥN	ΥN	YN	ΥN	Y N
wash cycle	Button trap	YN	ΥN	Y N	ΥN	Y N
ycl	Filter housings	YN	ΥN	YN	ΥN	Y N
æ	Filter gaskets and seating	Y N	ΥN	Y N	ΥN	Y N
	Solvent tanks	Y N	ΥN	YN	ΥN	Y N
	Deodorizing and aeration valves on dryers	Y N	ΥN	Y N	ΥN	Y N
d	Air and exhaust ductwork	YN	ΥN	YN	ΥN	Y N
dry o	Heating and cooling coil doors	Y N	ΥN	Y N	ΥN	Y N
cycle	Hose connections, unions, couplings & valves	YN	ΥN	YN	ΥN	Y N
æ	Water seperators	Y N	ΥN	Y N	ΥN	Y N
	Lint trap	Y N	ΥN	Y N	ΥN	Y N
di	Hose connections, unions, couplings & valves	Y N	ΥN	Y N	ΥN	Y N
stil	Water seperators	Y N	ΥN	Y N	ΥN	Y N
lati	Distillation unit	Y N	ΥN	Y N	ΥN	Y N
on,	Solvent tanks	YN	ΥN	YN	ΥN	Y N
distillation, misc	Muck coolers	Y N	ΥN	Y N	ΥN	Y N
isc	Waste tanks and storage containers	Y N	ΥN	Y N	ΥN	Y N

Repair Log				
Inspection Date and Description of Repair	Date Part Ordered	Date Part Received	Date Part Installed	Date Repaired

Week:	1	2	3	4	5
Date:					
Staff Initials:					

Refrigerated Condenser Monitoring Log									
Week	1	2	3	4	5				
If your machine has pressure gauges: Record pressures of high and low pressure gauges.									
Are pressure gauges within the ranges specified in the manual?	Y N	Y N	Y N	Y N	Y N				
If your machine does NOT have pressure gauges: Record refrigerated condenser outlet temperature.									
Is the temperature gauge ≤45°F?	YN	ΥN	ΥN	ΥN	ΥN				
If you are operating a transfer machine: Record inlet and outlet temperatures weekly.									
Calculate the difference (inlet - outlet)									
Is the difference $\geq 20^{\circ} F$	Y N	ΥN	YN	ΥN	YN				

Secondary Carbon Absorber Monitoring								
Week	1	2	3	4	5			
Is perc concentration less than 100 ppm? (for machines that vent to carbon adsorbers immediately upon machine door opening)	Y N	Y N	Y N	Y N	Y N			
Is perc concentration less than 300 ppm? (for machines that vent to carbon adsorbers prior to machine door opening)	Y N	Y N	Y N	Y N	Y N			

Perc Purchases Running Total									
Total from	Last Month								
Subtract Perc Purchased APRIL 2007		-							
Sul	ototal								
Purchase Date	Purchase Amount	12 Month Running Total							
	+								
	+								



April 2008

Sun	Mon	Tue	Wed	Thu	Fri	Sat
		1	2	3	4 Temp logged Inspect logged	5
6	7	8	9	10	11 Temp logged Inspect logged	12
13	14	15	16	17	18 Temp logged Inspect logged	19
20	21	22	23	24	25 Temp logged Inspect logged	26
27	28	29	30			

Virginia Department of Environmental Quality Small Business Assistance Program PO Box 1105 Richmond, VA 23218-1105

Toll-Free: 800.592.5482 ext. 4394 (in-state only) Telephone: 804.698.4394 Fax: 804.698.4264

osba@deq.virginia.gov



Complete April 2008 chart in the **Waste Generation/Treatment Log** on page 38.

Good idea: Maintain the solvent-to-carbon ratio and steam pressure for carbon beds in accordance with the manufacturer's specifications.





W	Weekly Equipment Inspections								
Are	Are the components without leaks? Circle Y for yes, or N for no.								
Method: choose one. Circle P for touch, sight or smell, or D for use of detector			P D	P D	P D	P D			
	Week	1	2	3	4	5			
	Hose connections, unions, couplings & valves	ΥN	ΥN	YN	ΥN	Y N			
<	Machine door gasket and seating	YN	YN	YN	ΥN	YN			
vas	Pumps	ΥN	ΥN	YN	ΥN	YN			
wash cycle	Button trap	ΥN	ΥN	YN	ΥN	ΥN			
ycl	Filter housings	ΥN	ΥN	YN	ΥN	ΥN			
æ	Filter gaskets and seating	YN	YN	YN	ΥN	YN			
	Solvent tanks	ΥN	ΥN	YN	ΥN	Y N			
	Deodorizing and aeration valves on dryers	ΥN	ΥN	YN	ΥN	ΥN			
₫	Air and exhaust ductwork	Y N	ΥN	YN	ΥN	Y N			
dry c	Heating and cooling coil doors	ΥN	ΥN	YN	ΥN	Y N			
cycle	Hose connections, unions, couplings & valves	Y N	Y N	YN	ΥN	Y N			
æ	Water seperators	Y N	Y N	YN	ΥN	Y N			
	Lint trap	Y N	Y N	YN	ΥN	Y N			
ď	Hose connections, unions, couplings & valves	Y N	Y N	YN	ΥN	Y N			
Still	Water seperators	Y N	Y N	YN	ΥN	Y N			
distillation,	Distillation unit	Y N	ΥN	YN	ΥN	Y N			
on,	Solvent tanks	Y N	ΥN	YN	ΥN	Y N			
misc	Muck coolers	YN	YN	YN	ΥN	Y N			
SC	Waste tanks and storage containers	YN	YN	YN	YN	Y N			

Repair Log				
Inspection Date and Description of Repair	Date Part Ordered	Date Part Received	Date Part Installed	Date Repaired

Week:	1	2	3	4	5
Date:					
Staff Initials:					

Refrigerated Condenser Monitoring Log									
Week	1	2	3	4	5				
If your machine has pressure gauges: Record pressures of high and low pressure gauges.									
Are pressure gauges within the ranges specified in the manual?	Y N	Y N	Y N	Y N	Y N				
If your machine does NOT have pressure gauges: Record refrigerated condenser outlet temperature.									
Is the temperature gauge ≤45°F?	ΥN	ΥN	ΥN	ΥN	ΥN				
If you are operating a transfer machine: Record inlet and outlet temperatures weekly.									
Calculate the difference (inlet - outlet)									
Is the difference ≥ 20°F	YN	YN	Y N	Y N	YN				

Secondary Carbon Absorber Monitoring								
Week	1	2	3	4	5			
Is perc concentration less than 100 ppm? (for machines that vent to carbon adsorbers immediately upon machine door opening)	Y N	Y N	Y N	Y N	Y N			
Is perc concentration less than 300 ppm? (for machines that vent to carbon adsorbers prior to machine door opening)	ΥN	ΥN	ΥN	ΥN	Y N			

Perc Purchases Running Total							
Total from	Last Month						
Subtract Perc Purchased MAY 2007		-					
Sul	ototal						
Purchase Date	Purchase Amount	12 Month Running Total					
	+						
	+						



May 2008

Sun	Mon	Tue	Wed	Thu	Fri	Sat
				1	2 Temp logged Inspect logged	3
4	5	6	7	8	9 Temp logged Inspect logged	10
11	12	13	14	15	16 Temp logged Inspect logged	17
18	19	20	21	22	23 Temp logged Inspect logged	24
25	26	27	28	29	30 Temp logged Inspect logged	31

Virginia Department of Environmental Quality Small Business Assistance Program PO Box 1105 Richmond, VA 23218-1105

Toll-Free: 800.592.5482 ext. 4394 (in-state only) Telephone: 804.698.4394 Fax: 804.698.4264

osba@deq.virginia.gov



Complete May 2008 chart in the **Waste Generation/Treatment Log** on page 38.

Good idea: All dry cleaning equipment should be operated and maintained according to the manufacturer's instructions found in the operation and maintenance manuals.





June 2008

W	Weekly Equipment Inspections								
Are	Are the components without leaks? Circle Y for yes, or N for no.								
	ethod: choose one. Circle P for touch, sight smell, or D for use of detector	P D	P D	P D	P D	P D			
	Week	1	2	3	4	5			
	Hose connections, unions, couplings & valves	ΥN	ΥN	YN	ΥN	YN			
<	Machine door gasket and seating	YN	YN	YN	YN	YN			
vas	Pumps	ΥN	ΥN	YN	YN	YN			
wash cycle	Button trap	Y N	ΥN	YN	YN	Y N			
ycl	Filter housings	Y N	ΥN	Y N	YN	Y N			
æ	Filter gaskets and seating	Y N	ΥN	Y N	YN	Y N			
	Solvent tanks	Y N	YN	Y N	YN	Y N			
	Deodorizing and aeration valves on dryers	ΥN	ΥN	ΥN	ΥN	YN			
₫	Air and exhaust ductwork	ΥN	ΥN	YN	ΥN	Y N			
dry cycle	Heating and cooling coil doors	ΥN	YN	YN	ΥN	Y N			
<u>yc</u>	Hose connections, unions, couplings & valves	Y N	ΥN	YN	ΥN	Y N			
æ	Water seperators	ΥN	ΥN	YN	ΥN	Y N			
	Lint trap	ΥN	ΥN	YN	ΥN	Y N			
<u>di</u>	Hose connections, unions, couplings & valves	Y N	ΥN	YN	ΥN	Y N			
still	Water seperators	ΥN	ΥN	YN	ΥN	Y N			
lati	Distillation unit	ΥN	ΥN	YN	ΥN	YN			
on,	Solvent tanks	ΥN	ΥN	YN	YN	YN			
distillation, misc	Muck coolers	ΥN	ΥN	ΥN	ΥN	YN			
İSC	Waste tanks and storage containers	YN	YN	YN	YN	YN			

Repair Log				
Inspection Date and Description of Repair	Date Part Ordered	Date Part Received	Date Part Installed	Date Repaired

Week:	1	2	3	4	5
Date:					
Staff Initials:					

Refrigerated Condenser Monitoring Log								
Week	1	2	3	4	5			
If your machine has pressure gauges: Record pressures of high and low pressure gauges.								
Are pressure gauges within the ranges specified in the manual?	Y N	Y N	Y N	Y N	Y N			
If your machine does NOT have pressure gauges: Record refrigerated condenser outlet temperature.								
Is the temperature gauge ≤45°F?	ΥN	ΥN	ΥN	ΥN	ΥN			
If you are operating a transfer machine: Record inlet and outlet temperatures weekly.								
Calculate the difference (inlet - outlet)								
Is the difference ≥ 20°F	YN	YN	Y N	Y N	YN			

Secondary Carbon Absorber Monitoring								
Week	1	2	3	4	5			
Is perc concentration less than 100 ppm? (for machines that vent to carbon adsorbers immediately upon machine door opening)	Y N	Y N	Y N	Y N	Y N			
Is perc concentration less than 300 ppm? (for machines that vent to carbon adsorbers prior to machine door opening)	ΥN	Y N	Y N	Y N	Y N			

Perc Purchases Running Total							
Total from	Last Month						
Subtract Perc Purchased JUNE 2007		-					
Sul	ototal						
Purchase Date	Purchase Amount	12 Month Running Total					
	+						
	+						



June 2008

Sun	Mon	Tue	Wed	Thu	Fri	Sat
1	2	3	4	5	6 Temp logged Inspect logged	7
8	9	10	11	12	13 Temp logged Inspect logged	14
15	16	17	18	19	20 Temp logged Inspect logged	21
22	23	24	25	26	27 Temp logged Inspect logged	28
29	30					

Virginia Department of Environmental Quality Small Business Assistance Program PO Box 1105 Richmond, VA 23218-1105

Toll-Free: 800.592.5482 ext. 4394 (in-state only) Telephone: 804.698.4394 Fax: 804.698.4264

osba@deq.virginia.gov




Complete June 2008 chart in the **Waste Generation/Treatment Log** on page 38.



By July 27, 2008, all dry cleaning facilities must submit to DEQ and EPA a Notification of Compliance Status, by registered mail. The form is provided in the July calendar section.

After July 27, 2008, all drycleaners must discontinue the use of transfer machine systems.





Ç	July	2008
	ı	

W	Weekly Equipment Inspections								
Are the components without leaks? Circle Y for yes, or N for no.									
	ethod: choose one. Circle P for touch, sight smell, or D for use of detector	P D	P D	P D	P D	P D			
	Week	1	2	3	4	5			
	Hose connections, unions, couplings & valves	YN	ΥN	ΥN	ΥN	ΥN			
S	Machine door gasket and seating	YN	ΥN	YN	ΥN	Y N			
/as	Pumps	YN	ΥN	ΥN	ΥN	ΥN			
wash cycle	Button trap	YN	ΥN	ΥN	ΥN	ΥN			
ycl	Filter housings	ΥN	ΥN	ΥN	ΥN	ΥN			
æ	Filter gaskets and seating	YN	ΥN	ΥN	ΥN	ΥN			
	Solvent tanks	YN	ΥN	YN	ΥN	YN			
	Deodorizing and aeration valves on dryers	ΥN	ΥN	ΥN	ΥN	ΥN			
٩	Air and exhaust ductwork	YN	ΥN	ΥN	ΥN	YN			
dry o	Heating and cooling coil doors	YN	ΥN	ΥN	ΥN	ΥN			
cycle	Hose connections, unions, couplings & valves	YN	ΥN	YN	ΥN	YN			
ē	Water seperators	YN	ΥN	ΥN	ΥN	ΥN			
	Lint trap	YN	ΥN	Y N	ΥN	Y N			
di	Hose connections, unions, couplings & valves	YN	ΥN	YN	ΥN	YN			
stil	Water seperators	YN	ΥN	ΥN	ΥN	ΥN			
lati	Distillation unit	YN	ΥN	YN	ΥN	ΥN			
distillation,	Solvent tanks	Y N	ΥN	ΥN	ΥN	Y N			
misc	Muck coolers	YN	ΥN	ΥN	ΥN	ΥN			
isc	Waste tanks and storage containers	Y N	YN	YN	ΥN	YN			

Repair Log				
Inspection Date and Description of Repair	Date Part Ordered	Date Part Received	Date Part Installed	Date Repaired

Week:	1	2	3	4	5
Date:					
Staff Initials:					

Refrigerated Condenser Monitoring Log								
Week	1	2	3	4	5			
If your machine has pressure gauges: Record pressures of high and low pressure gauges.								
Are pressure gauges within the ranges specified in the manual?	Y N	Y N	Y N	Y N	Y N			
If your machine does NOT have pressure gauges: Record refrigerated condenser outlet temperature.								
Is the temperature gauge ≤45°F?	Y N	ΥN	ΥN	ΥN	ΥN			
If you are operating a transfer machine: Record inlet and outlet temperatures weekly.								
Calculate the difference (inlet - outlet)								
Is the difference $\geq 20^{\circ} F$	Y N	ΥN	ΥN	ΥN	YN			

Secondary Carbon Absorber Monitoring						
Week	1	2	3	4	5	
Is perc concentration less than 100 ppm? (for machines that vent to carbon adsorbers immediately upon machine door opening)	Y N	Y N	Y N	Y N	Y N	
Is perc concentration less than 300 ppm? (for machines that vent to carbon adsorbers prior to machine door opening)	Y N	Y N	Y N	Y N	Y N	

Perc Purchases Running Total							
Total from	Last Month						
Subtract Perc Purchased JULY 2007		-					
Sul	ototal						
Purchase Date	Purchase Amount	12 Month Running Total					
	+						
	+						

COMMONWEALTH OF VIRGINIA DEPARTMENT OF ENVIRONMENTAL QUALITY

Dry Cleaners - 2008 Notification of Compliance Status

The owner or operator of a dry cleaning facility must submit a Notification of Compliance Status to DEQ and EPA by July 28, 2008 via registered mail.

Name and Address of Owner or Operator of Facility	
Name:	
Street Address:	
City:	Zip:
Name and Physical Location of the Facility	
Facility Name:	
Street Address:	
City:	Zip:
Is this shop located in a building with a residence(s), even if the residence is vacant at the time of this notification?	YesNo
Is this shop located in a building with no other tenants, leased space, or owner occupants?	YesNo
Is this shop a major source or area source?	Major Source Area Source
Is this shop in compliance with each of the applicable requirement of federal Dry Cleaning Rule found in §63.322?	YesNo
Facility's Yearly PCE Solvent Consumption based upon the yearly solvent consumption calculated according to the federal requirements found in §63.323(d) of the Dry Cleaning Rule:	Imption calculated according to the fed-
TT. 5 D	

The Responsible Official must certify below that all the information presented in this notification is accurate and

I certify the information contained in this notification to be accurate and true to the best of my knowledge and that this facility is in compliance with all applicable control device and monitoring requirements found in federal Dry Cleaning Rule found in §63.322.

	•
	•
	:
	•
le	•
Title	
	Ç
	,
	;
	•
e	
Name	;
	(
d)	
natur	•
Sign	,
ficial Signature	•
le Of	
nsibl	
Responsible Off	
R	,

Return one copy of this form to the Air Compliance Manager of the Virginia Department of Environmental Quality regional office covering your locality (regional office information provided on the following page) and one copy to the U.S. EPA Region III. Remember to keep a copy for your records.

US EPA Region III
Air Protection Division
Attn: Kristen Hall
Air Enforcement Branch
1650 Arch Street (3AP00)
Philadelphia, PA 19103-2029

The Northern Regional Office serves the counties of Arlington, Caroline, Culpeper, Fairfax, Fauquier, King George, Loudoun, Louisa, Madison, Orange, Prince William, Rappahannock, Spotsylvania and Stafford; and the cities of Alexandria, Fairfax, Falls Church, Fredericksburg, Manassas and Manassas Park. For more information, call (703) 583-3800.

DEQ Northern Regional Office Woodbridge, VA 22193-1453 Air Compliance Manager 13901 Crown Ct

The Piedmont Regional Office serves the counties of Amelia, Brunswick, Charles City, Chesterfield, Dinwiddie, Essex, Gloucester, Goochland, Greensville, Hanover, Henrico, King and Queen, King William, Lancaster, Mathews, Middlesex, New Kent, Northumberland, Powhatan, Prince George, Richmond, Surry, Sussex and Westmoreland; and the cities of Colonial Heights, Emporia, Hopewell, Petersburg and Richmond. For more information, call (804) 527-5020.

DEQ Piedmont Regional Office Air Compliance Manager 4949-A Cox Rd

Glen Allen, VA 23060-6201

The **Tidewater Regional Office** serves the counties of Accomack, Isle of Wight, James City, Northampton, Southampton and York; and the cities of Chesapeake, Franklin, Hampton, Newport News, Norfolk, Poquoson, Portsmouth, Suffolk, Virginia Beach and Williamsburg. For more information, call (757) 518-2000.

DEQ Tidewater Regional Office Virginia Beach, VA 23462-2407 Air Compliance Manager 5636 Southern Blvd

The **South Central Regional Office** serves the counties of Amherst, Appomattox, Buckingham, Campbell, Charlotte, Cumberland, Halifax, Lunenburg, Mecklenburg, Nottoway, Pittsylvania and Prince Edward; and the cities of Danville and Lynchburg. For more information, call (434) 582-5120.

DEQ South Central Regional Office Air Compliance Manager Lynchburg, VA 24502 7705 Timberlake Rd

The Southwest Regional Office serves the counties of Bland, Buchanan, Carroll, Dickenson, Grayson, Lee, Russell, Scott, Smyth, Tazewell, Washington, Wise and Wythe; and the cities of Bristol, Galax and Norton. For more information, call (276) 676-4800.

DEQ Southwest Regional Office Abington, VA 24212-1688 Air Compliance Manager PO BOX 1688

The **Valley Regional Office** serves the counties of Albemarle, Augusta, Bath, Clarke, Fluvanna, Frederick, Greene, Highland, Nelson, Page, Rockbridge, Rockingham, Shenandoah and Warren; and the cities of Buena Vista, Charlottesville, Harrisonburg, Lexington, Staunton, Waynesboro and Winchester. For more information, call (540) 574-7800.

DEQ Valley Regional Office PO BOX 3000 Air Compliance Manager

Harrisonburg, VA 22801-9519

The West Central Regional Office serves the counties of Alleghany, Bedford, Botetourt, Craig, Floyd, Franklin, Giles, Henry, Montgomery, Patrick, Pulaski and Roanoke; and the cities of Bedford, Clifton Forge, Covington, Martinsville, Radford, Roanoke and Salem. For more information, call (540) 562-6700.

DEQ West Central Regional Office Roanoke, VA 24019-2738 3019 Peters Creek Rd NW Air Compliance Manager



July 2008

Sun	Mon	Tue	Wed	Thu	Fri	Sat
		1	2	3	4 Temp logged Inspect logged	5
6	7	8	9	10	11 Temp logged Inspect logged	12
13	14	15	16	17	18 Temp logged Inspect logged	19
20	21	22	23	24	25 Temp logged Inspect logged	26
27	28	29	30	31		



Beginning on July 28, 2008, you must inspect your machine and its components on a monthly basis using a "Halogenated Hydrocarbon Detector," if your machine was installed prior to July 27, 2006. If your machine was installed on or after July 27, 2006, you must begin using the Halogenated Hydrocarbon Detector from the date of installation of your machine.

Complete July 2008 chart in the **Waste Generation/Treatment Log** on page 38.



By July 27, 2008, all dry cleaning facilities must submit to DEQ and EPA a Notification of Compliance Status, by registered mail. After July 27, 2008, all drycleaners must discontinue the use of transfer machine systems.

Virginia Department of Environmental Quality Small Business Assistance Program PO Box 1105 Richmond, VA 23218-1105

Toll-Free: 800.592.5482 ext. 4394 (in-state only) Telephone: 804.698.4394 Fax: 804.698.4264

osba@deq.virginia.gov



Page 18



August 2008

W	Weekly Equipment Inspections						
Are	e the components without leaks? Circle Y fo	r yes,	or N fo	r no.			
	ethod: choose one. Circle P for touch, sight smell, or D for use of detector	P D	P D	P D	P D	P D	
	Week	1	2	3	4	5	
	Hose connections, unions, couplings & valves	ΥN	ΥN	YN	ΥN	YN	
<	Machine door gasket and seating	YN	YN	YN	YN	YN	
vas	Pumps	ΥN	ΥN	YN	YN	YN	
wash cycle	Button trap	Y N	ΥN	YN	YN	Y N	
ycl	Filter housings	Y N	ΥN	Y N	YN	Y N	
æ	Filter gaskets and seating	Y N	ΥN	Y N	YN	Y N	
	Solvent tanks	Y N	ΥN	Y N	YN	Y N	
	Deodorizing and aeration valves on dryers	ΥN	ΥN	YN	ΥN	YN	
₫	Air and exhaust ductwork	ΥN	ΥN	YN	ΥN	YN	
dry cycle	Heating and cooling coil doors	ΥN	YN	YN	ΥN	YN	
<u>yc</u>	Hose connections, unions, couplings & valves	Y N	ΥN	YN	ΥN	Y N	
æ	Water seperators	ΥN	YN	YN	ΥN	YN	
	Lint trap	ΥN	YN	YN	ΥN	YN	
<u>di</u>	Hose connections, unions, couplings & valves	Y N	ΥN	YN	ΥN	Y N	
still	Water seperators	ΥN	YN	YN	ΥN	YN	
lati	Distillation unit	ΥN	ΥN	YN	ΥN	YN	
on,	Solvent tanks	ΥN	ΥN	YN	YN	YN	
distillation, misc	Muck coolers	ΥN	ΥN	ΥN	ΥN	YN	
İSC	Waste tanks and storage containers	YN	YN	YN	YN	YN	

Repair Log				
Inspection Date and Description of Repair	Date Part Ordered	Date Part Received	Date Part Installed	Date Repaired

٧	Veek:	1	2	3	4	5
D	ate:					
S	taff Initials:					

Refrigerated Condenser Monitoring Log								
Week	1	2	3	4	5			
If your machine has pressure gauges: Record pressures of high and low pressure gauges.								
Are pressure gauges within the ranges specified in the manual?	Y N	Y N	Y N	Y N	Y N			
If your machine does NOT have pressure gauges: Record refrigerated condenser outlet temperature.								
Is the temperature gauge ≤45°F?	ΥN	ΥN	ΥN	ΥN	ΥN			
If you are operating a transfer machine: Record inlet and outlet temperatures weekly.								
Calculate the difference (inlet - outlet)								
Is the difference ≥ 20°F	YN	YN	Y N	Y N	YN			

Secondary Carbon Absorber Monitoring							
Week	1	2	3	4	5		
Is perc concentration less than 100 ppm? (for machines that vent to carbon adsorbers immediately upon machine door opening)	Y N	Y N	Y N	Y N	Y N		
Is perc concentration less than 300 ppm? (for machines that vent to carbon adsorbers prior to machine door opening)	Y N	Y N	Y N	Y N	Y N		

Perc Purchases Running Total						
Total from	Last Month					
Subtract Perc Purchased AUGUST 2007		-				
Subtotal						
Purchase Date	Purchase Amount	12 Month Running Total				
	+					
	+					



August 2008

Sun	Mon	Tue	Wed	Thu	Fri	Sat
					1 Temp logged Inspect logged	2
3	4	5	6	7	8 Temp logged Inspect logged	9
10	11	12	13	14	15 Temp logged Inspect logged	16
17	18	19	20	21	22 Temp logged Inspect logged	23
24 31	25	26	27	28	29 Temp logged Inspect logged	30

Virginia Department of Environmental Quality Small Business Assistance Program PO Box 1105 Richmond, VA 23218-1105

Toll-Free: 800.592.5482 ext. 4394 (in-state only) Telephone: 804.698.4394 Fax: 804.698.4264

osba@deq.virginia.gov



Complete August 2008 chart in the **Waste Generation/Treatment Log** on page 38.

Good idea: All dry cleaning equipment should be operated and maintained according to the manufacturer's instructions found in the operation and maintenance manuals.





September 2008

Weekly Equipment Inspections							
Are	Are the components without leaks? Circle Y for yes, or N for no.						
	Method: choose one. Circle P for touch, sight or smell, or D for use of detector Week 1 2 3 4						
	Week	1	2	3	4	5	
	Hose connections, unions, couplings & valves	YN	ΥN	ΥN	ΥN	ΥN	
S	Machine door gasket and seating	YN	ΥN	YN	ΥN	Y N	
/as	Pumps	YN	ΥN	ΥN	ΥN	ΥN	
wash cycle	Button trap	YN	ΥN	ΥN	ΥN	ΥN	
ycl	Filter housings	ΥN	ΥN	ΥN	ΥN	ΥN	
æ	Filter gaskets and seating	YN	ΥN	ΥN	ΥN	ΥN	
	Solvent tanks	YN	ΥN	YN	ΥN	YN	
	Deodorizing and aeration valves on dryers	ΥN	ΥN	ΥN	ΥN	ΥN	
٩	Air and exhaust ductwork	YN	ΥN	ΥN	ΥN	YN	
dry o	Heating and cooling coil doors	YN	ΥN	ΥN	ΥN	ΥN	
cycle	Hose connections, unions, couplings & valves	YN	ΥN	YN	ΥN	YN	
ē	Water seperators	YN	ΥN	ΥN	ΥN	ΥN	
	Lint trap	YN	ΥN	Y N	ΥN	Y N	
di	Hose connections, unions, couplings & valves	YN	ΥN	YN	ΥN	YN	
stil	Water seperators	YN	ΥN	ΥN	ΥN	ΥN	
lati	Distillation unit	YN	ΥN	YN	ΥN	ΥN	
distillation,	Solvent tanks	Y N	ΥN	ΥN	ΥN	Y N	
misc	Muck coolers	YN	ΥN	ΥN	ΥN	ΥN	
isc	Waste tanks and storage containers	Y N	YN	YN	ΥN	YN	

Repair Log							
Inspection Date and Description of Repair	Date Part Ordered	Date Part Received	Date Part Installed	Date Repaired			

Week:	1	2	3	4	5
Date:					
Staff Initials:					

Refrigerated Condenser Monitoring Log								
Week	1	2	3	4	5			
If your machine has pressure gauges: Record pressures of high and low pressure gauges.								
Are pressure gauges within the ranges specified in the manual?	Y N	Y N	Y N	Y N	Y N			
If your machine does NOT have pressure gauges: Record refrigerated condenser outlet temperature.								
Is the temperature gauge ≤45°F?	Y N	ΥN	ΥN	ΥN	ΥN			
If you are operating a transfer machine: Record inlet and outlet temperatures weekly.								
Calculate the difference (inlet - outlet)								
Is the difference $\geq 20^{\circ} F$	Y N	ΥN	ΥN	ΥN	YN			

Secondary Carbon Absorber Monitoring							
Week	1	2	3	4	5		
Is perc concentration less than 100 ppm? (for machines that vent to carbon adsorbers immediately upon machine door opening)	Y N	Y N	Y N	Y N	Y N		
Is perc concentration less than 300 ppm? (for machines that vent to carbon adsorbers prior to machine door opening)	Y N	Y N	Y N	Y N	Y N		

Perc Purchases Running Total						
Total from	Last Month					
Subtract Perc Purchased SEPTEMBER 2007		-				
Subtotal						
Purchase Date	Purchase Amount	12 Month Running Total				
	+					
	+					



2009 Order Form and Survey

	a 2009 calendar.
	ill out all of the information below to request
-	n bel
	rmatio
	the info
	<u></u>
_	_
	out all of
=	Ţ.

copies of the 2009 Compliance Calendar.

Please send me_

Name:		
Business Name:		
Mailing Address:		
City: State:	Zip:	
Telephone Number: E-mail:		
Help us improve our calendar.		
This calendar is useful.	yes no	maybe
I keep better records when I use this calendar.	yes no	maybe
This calendar helped me understand environmental regulations.	yes no	maybe
This calendar helped my company minimize air emissions.	yes no	maybe
I would recommend the calendar to others.	yes no	maybe
I will use the calendar again next year.	yes no	maybe
How can DEQ improve this calendar?		
	I	
Help us help you.		
Did you attend a Spring 2007 workshop that DEQ offered for dry cleaners?		yes no
If yes, was the workshop useful?	yes no	maybe
How often do you think DEQ should offer such workshops?		
Is there any additional assistance we can provide you?		



2009 Order Form and Survey

Then make your request by mail, fax, e-mail or telephone. Fill out all of the information on the request form.

Mail VA DEQ, Small Business Assistance Program

Attn: Dana Brancolini

PO Box 1105

Richmond, VA 23218-1105

Fax (804) 698-4264

Email drbrancolini@deq.virginia.gov

Telephone (804) 698-4115

Thank you!

Virginia Department of Environmental Quality Small Business Assistance Program PO Box 1105 Richmond, VA 23218-1105

Toll-Free: 800.592.5482 ext. 4394 (in-state only) Telephone: 804.698.4394 Fax: 804.698.4264

osba@deq.virginia.gov





September 2008

Sun	Mon	Tue	Wed	Thu	Fri	Sat
	1	2	3	4	5 Temp logged Inspect logged	6
7	8	9	10	11	12 Temp logged Inspect logged	13
14	15	16	17	18	19 Temp logged Inspect logged	20
21	22	23	24	25	26 Temp logged Inspect logged	27
28	29	30				

Virginia Department of Environmental Quality Small Business Assistance Program PO Box 1105 Richmond, VA 23218-1105

Toll-Free: 800.592.5482 ext. 4394 (in-state only) Telephone: 804.698.4394 Fax: 804.698.4264

osba@deq.virginia.gov



Complete September 2008 chart in the **Waste Generation/Treatment Log** on page 38.

Good idea: Store all solvent and waste materials in containers, that are compatible with the storage of perc and perc waste (perc will not damage inside of container). These containers must be kept closed and marked as "Hazardous Waste."





October 2008

W	eekly Equipment Inspections					
Are	e the components without leaks? Circle Y fo	r yes,	or N fo	r no.		
	ethod: choose one. Circle P for touch, sight smell, or D for use of detector	P D	P D	P D	P D	P D
	Week	1	2	3	4	5
	Hose connections, unions, couplings & valves	YN	ΥN	ΥN	ΥN	YN
S	Machine door gasket and seating	Y N	ΥN	YN	ΥN	Y N
/as	Pumps	ΥN	ΥN	ΥN	ΥN	Y N
wash cycle	Button trap	ΥN	ΥN	ΥN	ΥN	YN
ycl	Filter housings	ΥN	ΥN	ΥN	ΥN	YN
Œ	Filter gaskets and seating	Y N	ΥN	ΥN	ΥN	YN
	Solvent tanks	YN	ΥN	ΥN	ΥN	YN
	Deodorizing and aeration valves on dryers	ΥN	ΥN	ΥN	ΥN	YN
₫	Air and exhaust ductwork	ΥN	ΥN	ΥN	ΥN	YN
dry c	Heating and cooling coil doors	Y N	ΥN	ΥN	ΥN	YN
cycle	Hose connections, unions, couplings & valves	Y N	ΥN	ΥN	ΥN	Y N
ē	Water seperators	ΥN	ΥN	ΥN	ΥN	Y N
	Lint trap	YN	ΥN	YN	ΥN	YN
<u>d</u>	Hose connections, unions, couplings & valves	Y N	ΥN	ΥN	ΥN	Y N
still	Water seperators	ΥN	ΥN	ΥN	ΥN	Y N
lati	Distillation unit	Y N	ΥN	YN	ΥN	YN
distillation,	Solvent tanks	YN	ΥN	ΥN	ΥN	YN
misc	Muck coolers	YN	ΥN	YN	ΥN	YN
İSC	Waste tanks and storage containers	YN	YN	YN	ΥN	YN

Repair Log				
Inspection Date and Description of Repair	Date Part Ordered	Date Part Received	Date Part Installed	Date Repaired

Week:	1	2	3	4	5
Date:					
Staff Initials:					

Refrigerated Condenser Monitoring Log									
Week	1	2	3	4	5				
If your machine has pressure gauges: Record pressures of high and low pressure gauges.									
Are pressure gauges within the ranges specified in the manual?	Y N	Y N	Y N	Y N	Y N				
If your machine does NOT have pressure gauges: Record refrigerated condenser outlet temperature.									
Is the temperature gauge ≤45°F?	Y N	ΥN	ΥN	ΥN	ΥN				
If you are operating a transfer machine: Record inlet and outlet temperatures weekly.									
Calculate the difference (inlet - outlet)									
Is the difference $\geq 20^{\circ} F$	Y N	ΥN	ΥN	ΥN	YN				

Secondary Carbon Absorber Monitoring								
Week	1	2	3	4	5			
Is perc concentration less than 100 ppm? (for machines that vent to carbon adsorbers immediately upon machine door opening)	Y N	Y N	Y N	Y N	Y N			
Is perc concentration less than 300 ppm? (for machines that vent to carbon adsorbers prior to machine door opening)	ΥN	ΥN	ΥN	Y N	Y N			

Perc Purchas	ses Running To	tal
Total from	Last Month	
Subtract Perc Purchased OCTOBER 2007		-
Sul	ototal	
Purchase Date	Purchase Amount	12 Month Running Total
	+	
	+	



October 2008

Sun	Mon	Tue	Wed	Thu	Fri	Sat
			1	2	3 Temp logged ☐ Inspect logged ☐	4
5	6	7	8	9	10 Temp logged Inspect logged	11
12	13	14	15	16	17 Temp logged Inspect logged	18
19	20	21	22	23	24 Temp logged Inspect logged	25
26	27	28	29	30	31 Temp logged Inspect logged	

Virginia Department of Environmental Quality Small Business Assistance Program PO Box 1105 Richmond, VA 23218-1105

Toll-Free: 800.592.5482 ext. 4394 (in-state only) Telephone: 804.698.4394 Fax: 804.698.4264

osba@deq.virginia.gov



Complete October 2008 chart in the **Waste Generation/Treatment Log** on page 38.

Good idea: All containers holding perc waste should be kept with the lid on. This includes any cartridge filters or condensate wastes.





November 2008

W	eekly Equipment Inspections					
Are	e the components without leaks? Circle Y fo	r yes,	or N fo	r no.		
	ethod: choose one. Circle P for touch, sight smell, or D for use of detector	P D	P D	P D	P D	P D
	Week	1	2	3	4	5
	Hose connections, unions, couplings & valves	YN	ΥN	ΥN	ΥN	ΥN
S	Machine door gasket and seating	YN	ΥN	YN	ΥN	Y N
/as	Pumps	YN	ΥN	ΥN	ΥN	ΥN
wash cycle	Button trap	YN	ΥN	ΥN	ΥN	ΥN
ycl	Filter housings	ΥN	ΥN	ΥN	ΥN	ΥN
æ	Filter gaskets and seating	YN	ΥN	YN	ΥN	ΥN
	Solvent tanks	YN	ΥN	YN	ΥN	YN
	Deodorizing and aeration valves on dryers	Y N	ΥN	ΥN	ΥN	ΥN
٩	Air and exhaust ductwork	YN	ΥN	ΥN	ΥN	YN
dry o	Heating and cooling coil doors	YN	ΥN	ΥN	ΥN	ΥN
cycle	Hose connections, unions, couplings & valves	YN	ΥN	YN	ΥN	YN
ē	Water seperators	YN	ΥN	ΥN	ΥN	ΥN
	Lint trap	YN	ΥN	Y N	ΥN	Y N
di	Hose connections, unions, couplings & valves	YN	ΥN	YN	ΥN	YN
stil	Water seperators	YN	ΥN	ΥN	ΥN	ΥN
lati	Distillation unit	YN	ΥN	YN	ΥN	ΥN
distillation,	Solvent tanks	Y N	ΥN	ΥN	ΥN	Y N
misc	Muck coolers	YN	ΥN	ΥN	ΥN	ΥN
isc	Waste tanks and storage containers	Y N	YN	YN	ΥN	YN

Repair Log				
Inspection Date and Description of Repair	Date Part Ordered	Date Part Received	Date Part Installed	Date Repaired

Week:	1	2	3	4	5
Date:					
Staff Initials:					

Refrigerated Condenser Monitoring Log								
Week	1	2	3	4	5			
If your machine has pressure gauges: Record pressures of high and low pressure gauges.								
Are pressure gauges within the ranges specified in the manual?	Y N	Y N	Y N	Y N	Y N			
If your machine does NOT have pressure gauges: Record refrigerated condenser outlet temperature.								
Is the temperature gauge ≤45°F?	Y N	ΥN	ΥN	ΥN	ΥN			
If you are operating a transfer machine: Record inlet and outlet temperatures weekly.								
Calculate the difference (inlet - outlet)								
Is the difference ≥ 20°F	Y N	YN	YN	ΥN	ΥN			

Secondary Carbon Absorber Monitoring								
Week	1	2	3	4	5			
Is perc concentration less than 100 ppm? (for machines that vent to carbon adsorbers immediately upon machine door opening)	Y N	Y N	Y N	Y N	Y N			
Is perc concentration less than 300 ppm? (for machines that vent to carbon adsorbers prior to machine door opening)	ΥN	ΥN	ΥN	Y N	Y N			

Perc Purchas	Perc Purchases Running Total						
Total from	Last Month						
Subtract Perc Purchased NOVEMBER 2007		-					
Sul	ototal						
Purchase Date	Purchase Amount	12 Month Running Total					
	+						
	+						



November 2008

Sun	Mon	Tue	Wed	Thu	Fri	Sat
						1
2	3	4	5	6	7 Temp logged Inspect logged	8
9	10	11	12	13	14 Temp logged Inspect logged	15
16	17	18	19	20	21 Temp logged Inspect logged	22
23 30	24	25	26	27	28 Temp logged Inspect logged	29

Virginia Department of Environmental Quality Small Business Assistance Program PO Box 1105 Richmond, VA 23218-1105

Toll-Free: 800.592.5482 ext. 4394 (in-state only) Telephone: 804.698.4394 Fax: 804.698.4264

osba@deq.virginia.gov



Complete November 2008 chart in the **Waste Generation/Treatment Log** on page 38.

Good idea: Tightly seal bungs and lids on containers of raw materials and wastes to stop evaporation.





December 2008

W	Weekly Equipment Inspections							
Are	e the components without leaks? Circle Y fo	r yes,	or N fo	r no.				
	ethod: choose one. Circle P for touch, sight smell, or D for use of detector	P D	P D	P D	P D			
	Week	1	2	3	4	5		
	Hose connections, unions, couplings & valves	YN	ΥN	Y N	ΥN	YN		
<	Machine door gasket and seating	YN	ΥN	YN	ΥN	YN		
vas	Pumps	YN	ΥN	Y N	ΥN	Y N		
wash cycle	Button trap	YN	ΥN	Y N	ΥN	YN		
ycl	Filter housings	YN	ΥN	YN	ΥN	Y N		
æ	Filter gaskets and seating	YN	ΥN	Y N	ΥN	Y N		
	Solvent tanks	YN	ΥN	YN	ΥN	Y N		
	Deodorizing and aeration valves on dryers	YN	ΥN	Y N	ΥN	Y N		
₫	Air and exhaust ductwork	YN	ΥN	ΥN	ΥN	YN		
dry c	Heating and cooling coil doors	YN	ΥN	ΥN	ΥN	YN		
cycle	Hose connections, unions, couplings & valves	YN	ΥN	YN	ΥN	YN		
ਜ	Water seperators	YN	ΥN	ΥN	ΥN	YN		
	Lint trap	YN	ΥN	ΥN	ΥN	YN		
di	Hose connections, unions, couplings & valves	YN	ΥN	YN	ΥN	YN		
stil	Water seperators	YN	ΥN	ΥN	ΥN	YN		
distillation,	Distillation unit	YN	ΥN	Y N	ΥN	YN		
on,	Solvent tanks	YN	ΥN	YN	ΥN	YN		
, misc	Muck coolers	YN	ΥN	ΥN	ΥN	YN		
isc	Waste tanks and storage containers	Y N	ΥN	YN	YN	YN		

Repair Log				
Inspection Date and Description of Repair	Date Part Ordered	Date Part Received	Date Part Installed	Date Repaired

Week:	1	2	3	4	5
Date:					
Staff Initials:					

Refrigerated Condenser Monitoring Log							
Week	1	2	3	4	5		
If your machine has pressure gauges: Record pressures of high and low pressure gauges.							
Are pressure gauges within the ranges specified in the manual?	Y N	Y N	Y N	Y N	Y N		
If your machine does NOT have pressure gauges: Record refrigerated condenser outlet temperature.							
Is the temperature gauge ≤45°F?	YN	ΥN	ΥN	ΥN	ΥN		
If you are operating a transfer machine: Record inlet and outlet temperatures weekly.							
Calculate the difference (inlet - outlet)							
Is the difference $\geq 20^{\circ} F$	Y N	ΥN	YN	ΥN	YN		

Secondary Carbon Absorber Monitoring						
Week	1	2	3	4	5	
Is perc concentration less than 100 ppm? (for machines that vent to carbon adsorbers immediately upon machine door opening)	Y N	Y N	Y N	Y N	Y N	
Is perc concentration less than 300 ppm? (for machines that vent to carbon adsorbers prior to machine door opening)	ΥN	ΥN	ΥN	Y N	Y N	

Perc Purchas	ses Running To	tal
Total from	Last Month	
	erc Purchased BER 2007	-
Sul	ototal	
Purchase Date	Purchase Amount	12 Month Running Total
	+	
	+	



December 2008

Sun	Mon	Tue	Wed	Thu	Fri	Sat
	1	2	3	4	5 Temp logged □ Inspect logged □	6
7	8	9	10	11	12 Temp logged □ Inspect logged □	13
14	15	16	17	18	19 Temp logged □ Inspect logged □	20
21	22	23	24	25	26 Temp logged □ Inspect logged □	27
28	29	30	31			

Virginia Department of Environmental Quality Small Business Assistance Program PO Box 1105 Richmond, VA 23218-1105

Toll-Free: 800.592.5482 ext. 4394 (in-state only) Telephone: 804.698.4394 Fax: 804.698.4264

osba@deq.virginia.gov



Complete December 2008 chart in the **Waste Generation/Treatment Log** on page 38.

VA SBAP

Virginia Small Business Assistance Program
Serving Business and the Environment

Good idea: After replacing filter gaskets and seals, check for tightness.



Definitions

Ancillary equipment - the equipment used with a dry cleaning machine in a dry cleaning system including, but not limited to, emission control devices, pumps, filters, muck cookers, stills, solvent tanks, solvent containers, water separators, exhaust dampers, diverter valves, interconnecting piping, hoses and ducts.

Biweekly - any 14-day period of time.

Carbon adsorber - a bed of activated carbon into which an air-perc vapor stream is routed and which adsorbs the perc on the carbon.

Colorimetric detector tube - a glass tube (sealed prior to use), containing a chemical that changes color when exposed to perc and is designed to measure the concentration of perc in air.

Construction - the onsite fabrication, erection, or installation of a dry cleaning system.

Diverter valve - a flow control device that prevents room air from passing through a refrigerated condenser when the door of the dry cleaning machine is open.

Dry cleaning machine drum - the perforated (meaning with holes in it) container inside the dry cleaning machine that holds the articles during dry cleaning.

Dry cleaning system - a dry-to-dry machine and its ancillary equipment, or a transfer machine system and its ancillary equipment.

Dryer - a machine used to remove perc from articles by tumbling them in a heated air stream (sometimes called reclaimer).

Dry-to-dry machine - a one-machine dry cleaning operation in which washing and drying are performed in the same machine.

Exhaust damper - a flow control device that prevents the air-perc vapor stream from exiting the dry cleaning machine into a carbon adsorber before room air is drawn into the dry cleaning machine.

Existing (for September 1993 rule) - commenced construction or reconstruction before December 9, 1991.

Existing (for **July 2006** rule) - commenced construction or reconstruction before December 21, 2005.

Filter - a porous device through which perc is passed to remove contaminants in suspension. Examples include, but are not limited to, lint filter, button trap, cartridge filter, tubular filter, regenerative filter, polishing filter and spin disc filter.

Halogenated hydrocarbon detector - a portable device capable of detecting vapor concentrations of perc of 25 parts per million (ppm) by volume and indicating a concentration of 25 ppm by volume or greater by emitting an audible or visual signal that varies as the concentration changes.

New (for **September 1993** rule) - commenced construction or reconstruction on or after December 9, 1991.

New (for July 2006 rule) - commenced construction or reconstruction on or after December 21, 2005.

PCE gas analyzer - a flame ionization detector, photoionization detector, or infrared analyzer capable of detecting vapor concentrations of perc of 25 parts per million by volume.

Definitions continued

Perceptible leaks - any perc vapor or liquid leaks that are obvious from:

- 1. the odor of perc;
- 2. visual observation, such as pools or droplets of liquid; or
- 3. the detection of gas flow by passing the fingers over the surface of equipment.

Reconstruction - replacement of a washer, dryer, or reclaimer; or replacement of any components of a dry cleaning system to such an extent that the fixed capital cost of the new components exceeds 50 percent of the fixed capital cost that would be required to construct a comparable new source.

Refrigerated condenser - a vapor recovery system into which an air-perc vapor stream is routed and the perc is condensed by cooling the gas-vapor stream.

Responsible official - one of the following:

- 1. for a corporation: a president, secretary, treasurer, or vice president of the corporation in charge of a principal business function, or any other person who performs similar policy or decision-making functions for the corporation, or a duly authorized representative of such person if the representative is responsible for the overall operation of one or more dry cleaning facilities;
- 2. for a partnership: a general partner;
- 3. for a sole proprietorship: the owner; or
- 4. for a municipality, State, Federal, or other public agency: either a principal executive officer or ranking official.

Still - any device used to volatilize and recover perc from contaminated perc.

Transfer machine system - a multiple-machine dry cleaning operation in which washing and drying are performed in different machines. Examples include, but are not limited to:

- 1. a washer and dryer(s);
- 2. a washer and reclaimer(s); or
- 3. a dry-to-dry machine and reclaimer(s).

Vapor leak - a perc vapor concentration exceeding 25 parts per million by volume (50 parts per million by volume as methane) as indicated by a halogenated hydrocarbon detector or PCE (perc) gas analyzer.

Washer - a machine used to clean articles by immersing them in perc. This includes a dry-to-dry machine when used with a reclaimer.

Water separator - any device used to recover perc from a water-perc mixture, includes evaporators.



Determining if the Regulations Affect Your Facility

Dry cleaners are impacted by state and federal regulations, which control perc emissions and which limit exposure to this chemical. These regulations require operational standards and control technology to reduce perc air emissions from dry cleaning operations. Whether or not your dry cleaning facility is affected by the regulations depends on the factors listed below.

- A. You are not regulated, if you are using a hydrocarbon (petroleum) dry cleaning machine or machines with less than a total dryer capacity of 84 lbs.
- B. You need an air permit from DEQ, if you are using a hydrocarbon machine or machines with a combined dryer capacity of greater than 84 lbs.
- C. You are regulated, if you are using a perc dry-to-dry dry cleaning machine. The following factors determine your business classification: the date of purchase and installation of the machine, and the amount of perc you use on an annual basis.
 - 1. The dates of purchase and installation classify your business as "Existing" or "New." For dry cleaning shops that are not located in a building containing a residence, there are three important dates that determine the type of controls and records that are necessary for your machine: December 9, 1991*; September 22, 1993*; and December 21, 2005.
 - a. Any new or used machine installed after December 21, 2005 must be a "Generation 4" machine, which means that it must be dry-to-dry with a refrigerated condenser and it must recirculate the perc-vapor stream through a non-vented carbon adsorber prior to the door being opened.
 - b. All dry cleaners in existence prior to July 27, 2006 must comply with the new monitoring and record keeping requirements by July 28, 2008. You must be in compliance with all monitoring and record keeping requirements on the date of installation. For more information, see National Perchloroethylene (Perc) Air Emissions Standards for Dry Cleaning Facilities (e-CFR), July 27, 2006 (use the e-CFR link at http://www.deq.virginia.gov/osba/indsect.html#dry).
 - c. All dry cleaners are required to submit a Notification of Compliance (found in the calendar) to both EPA Region III in Philadelphia and to their DEQ Regional Office by July 27, 2008 indicating that they are in compliance with all provisions of the rule including both the 1993 and the 2006 provisions.
 - 2. The amount of perc used on an annual basis classifies your business as small, large or major.
 - 3. The following factors determine the types of controls that are necessary for your machine, the monitoring you must perform and records you must keep: date of installation and the classification of the business as existing or new, and as small, large or major.

^{*} Machines installed before Dec. 9, 1991 or after Sept 22, 1993, but before Dec. 21, 2005 that use more 140 gals of perc on annual basis must have a refrigerated condenser and must complete the weekly inspection and the refrigerated condenser record keeping.


Store Classification and Requirements

This chart will help you classify your facility, determine what controls you need, and determine what leak detection and monitoring is required.

Classification Based on Yearly Perc Usage	Classification Based on Date Ma- chine Purchased and Installed	Controls Required	Leak Detection Monitoring Required
Small Area Source dry-to-dry only: less than 140 gals transfer only: less than 200 gals* both types: less than 140 gals*	Existing New or used dry cleaning machine initially installed before December 21, 2005.	Refrigerated Condenser (unless installed before December 9, 1991, then no nontrols are required)	Monthly: halogenated hydrocarbon detector (starting July 28, 2008) Every 2 Weeks: perceptible leak check (smell, touch, sight)
both types. 1055 than 110 gais	New New or used dry cleaning machine initially installed on or after December 21, 2005.	Refrigerated Condenser Must recirculate perc vapor stream through non-vented carbon absorber before door can open	Monthly: halogenated hydrocarbon detector (starting July 27, 2006, or on date installed) Every 2 Weeks: perceptible leak check (smell, touch, sight)
Large Area Source dry-to-dry only: 140 gals up to 2,100 gals transfer only: 200 gals up to 1,800 gals* both types: 140 gals up to 1,800 gals*	Existing New or used dry cleaning machine initially installed before December 21, 2005.	Refrigerated Condenser (unless installed before September 22, 1993, then Refrigerated Condenser, or Existing Carbon Absorber)	Monthly: halogenated hydrocarbon detector (starting July 28, 2008) Every 2 Weeks: perceptible leak check (smell, touch, sight)
both types. 140 gais up to 1,000 gais	New New or used dry cleaning machine initially installed on or after December 21, 2005.	Refrigerated Condenser Must recirculate perc vapor stream through non-vented carbon absorber before door can open	Monthly: halogenated hydrocarbon detector (starting July 27, 2006, or on date installed) Every 2 Weeks: perceptible leak check (smell, touch, sight)
Major Source dry-to-dry only: 2,100 gals or more transfer only: 1,800 gals or more* both types: 1,800 gals or more*	Date of purchase or installation does not make any difference in determination of this category	Refrigerated Condenser + Room Enclosure + Carbon Absorber	Monthly: perc (PCE) gas analyzer (starting July 28, 2008) Every 2 Weeks: perceptible leak check (smell, touch, sight)

^{*} Transfer systems may not be used after July 27, 2008. For those systems that are still in use, the refrigerated condenser on the washer must be checked for temperature on a weekly basis.

See page 34 for special requirements that apply to perc machines in co-residential facilities (dry cleaning stores in the same building as a residence, such as house, apartment building, condominium building, or hotel).





Registration and Permits

Registration

All dry cleaners are required to register with DEQ. All dry cleaners are required to submit the following forms: Initial Notification Report Form (pink), Compliance Report Form (blue), and Pollution Prevention Report Form (yellow). If you add machines, change-out machines, move your store, or change ownership, you should notify your DEQ regional office of the change within 30 days, using a new Initial Notification Report Form.

New Source Review Permits

New Source Review permits (construction and operation permits) may be required depending upon the size and classification of your dry cleaning store.

Title V Permit

Only major sources are required to obtain a Title V Operating Permit. All area sources are exempt from a Title V Operating Permit.

Major Source

If your facility is a major source, you are required to obtain a Title V Air Permit and a New Source Review Permit. Call Richard Rasmussen at (804) 698-4394 or 1-800-592-5482 ext. 4394, if you are a major source and need help understanding your requirements.

Exemptions — the following facilities are exempt:

- dry cleaning facilities using petroleum solvents, or synthetic solvents other than perc
- coin operated dry cleaning facilities
- Drop-off only stores

Additional Requirements

- 1. Have available on-site a copy of the design specifications and the operating manuals for each dry cleaning system and each emission control device.
- 2. Close the door to the machine immediately after transferring articles to or from the machine, and shall keep the door closed at all other times.
- 3. Drain all cartridge filters in their housing, or other sealed container, for a minimum of 24 hours, or treat such filters in an equivalent manner before removal from the dry cleaning facility.
- 4. Store all perc waste and any wastes that contain perc such as cartridge filters.
- 5. Operate each dry cleaning machine, or a reclaimer with a refrigerated condenser in a manner to not vent or release the air-perc gas vapor stream contained within the dry cleaning machine to the atmosphere while the dry cleaning machine drum is rotating.
- 6. Operate each dry cleaning machine or reclaimer to prevent any air drawn into the dry cleaning machine when the door of the machine is open from passing through the refrigerated condenser.
- 7. Do not bypass any carbon adsorber used on a dry-to-dry dry cleaning machine or transfer system in an attempt to vent, or release any air-perc gas-vapor stream to the atmosphere at any time.

Co-Residential Requirements

The requirements listed below apply only to dry cleaning machines located in buildings with a residence, such as a house, apartment building, hotel, or condominium.

EPA has strengthened the requirements for dry cleaning facilities located buildings in which people reside, such as houses, apartments, condos and co-ops. Because residences in these co-residential buildings are located very close to these dry cleaners, residents' exposures and potential health risks can be much higher than for typical facility.

Co-Residential Facilities with Machines Installed before December 21, 2005


- May not use a transfer machine.
- May continue to use an existing installed perc machine at the shop until it wears out, but not beyond December 21, 2020.
- May not relocate an existing perc machine from elsewhere to the shop.

Co-Residential Facilities with Machines Installed between December 21, 2005 and July 12, 2006

- May not use a transfer machine.
- May use an existing installed perc machine at the shop, but only inside a vapor barrier enclosure with its exhaust system operating at all times the dry cleaning machine operates and during maintenance.
 - The door to the enclosure may only be open when a person is entering or leaving the enclosure.
 - The perc dry cleaning machine must have a refrigerated condenser and carbon adsorber (also called a "generation 4" machine).
- May not use a perc machine on or after July 27, 2009.

Co-Residential Facilities with Machines Installed On or After July 27, 2006

- May not use a perc machine after July 27, 2009.
- Must have a vapor barrier enclosure.



Visit www.deq.virginia.gov/regions/homepage.html, for more information.

Helpful Contacts and Resources

DEQ Offices and Contacts

Small Business Assistance Program: Richard Rasmussen, (804) 698-4394, or 1-800-592-5482 ext.4394

Rodney Sobin, (804)698-4382, or 1-800-592-5482 ext.4382

Northern Regional Office: Dave Hartshorn, (703) 583-3895

Fredericksburg Satellite Office: James LaFrata, (540) 899-4507

Terry Darton, (540) 899-4505, or (703) 583-3845

Piedmont Regional Office: Boots King, (804) 527-5036 **Tidewater Regional Office:** Ken Pinzel, (757) 518-2191

South Central Regional Office: Craig Nicol, (434) 582-6229 **Southwest Regional Office:** Crystal Bazyk, (276) 676-4829

Valley Regional Office: Ron Phillips, (540) 574-7846

West Central Regional Office: Frank Adams, (540) 562-6773

Online Resources

Virginia Small Business Assistance Program (DEQ Office of Small Business Assistance)

http://www.deg.virginia.gov/osba/

In the Dry Cleaners section on the Business and Industry Resources page, you will find the following resources:

- VA DEQ: 2008 Dry Cleaning Compliance Calendar
- VA DEQ Environmental Compliance Refresher: educational/training seminar schedule, Regulatory Update presentation, Annual Emission Update presentation, and Spills and Remediation presentation
- EPA: National Perchloroethylene (Perc) Air Emissions Standards for Dry Cleaning Facilities (e-CFR), July 27, 2006
- EPA Fact Sheet: Final Amendments to Air Toxics Standards for Perchloroethylene Dry Cleaners (English)
- EPA Fact Sheet: Final Amendments to Air Toxics Standards for Perchloroethylene Dry Cleaners (Korean)
- EPA: Dry Cleaning Emission Standards, overview page on Office of Air and Radiation
- EPA: Rule and Implementation Information for Perchloroethylene Dry Cleaning Facilities, EPA Air Toxics Web Site
- OSHA: Reducing Worker Exposure to Perc in Dry Cleaning
- EPA: The Plain English Guide for Dry Cleaners: A Step-by-step Approach to Understanding Federal Environmental Regulations
- EPA: The Plain Korean Guide for PERC Dry Cleaners: A Step-by-step Approach to Understanding Federal Environmental Regulations
- VA DEQ: Wet Cleaning: An Alternative to Dry Cleaning that Is Safe For You, Your Clothes and Your Cleaner
- EPA: Garment & Textile Care Partnership, Design for the Environment
- EPA Hazardous Waste: RCRA In Focus: Dry Cleaning (English)
- EPA Hazardous Waste: RCRA In Focus: Dry Cleaning (Korean)



Hazardous Waste Requirements

Overview

All dry cleaners generate wastes that are considered hazardous waste. A hazardous waste is any material that has come into contact with perc and that needs disposal. Hazardous waste may include your still bottoms/muck from the muck cooker; the lint from your lint filter; the carbon filters that you may have on your evaporator or atomizer (mister); the residue that you may have in your perc/water separator, and the rags or kitty litter that you may use to clean up a spill.


Most dry cleaners are considered Conditionally Exempt Small Quantity Generators (CESQG) of hazardous waste, in other words. To be classified as CESQG, the store must generate less than 25 gallons or 220 pounds of waste per month. If you generate more, then you are considered a Small Quantity Generator (SQG). SQGs have additional requirements that are necessary to comply with Virginia's Hazardous Waste Regulations. A Small Quantity Generator must have an EPA ID Number, which will look like "VAD 123456789." DEQ recommends that Conditionally Exempt Small Quantity Generators also apply for an EPA ID Number. For more information, call Dan Gwinner at (804) 698-4218.

All containers that are holding hazardous waste must be kept closed at all times and must be labeled "Hazardous Waste." Perc is very hazardous. If spilled, perc should be cleaned up immediately. It can penetrate concrete and can contaminate the environment (ground and water). While Virginia does not have a dry clean-up, DEQ provides a resource program called the Virginia Voluntary Remediation Program. This program can help dry cleaners with a clean-up, making the clean-up cots considerably less expensive than it might be without the program's assistance. For information, call Kevin Greene at (804) 698-4236.

You must ensure that the company that is picking up your hazardous waste is permitted to do so in Virginia. Each drum that is shipped should have a manifest that is supplied by the shipper. If you are Conditionally Exempt, the shipper will use it's EPA ID Number. If you have your own, your number should go on the manifest as the shippers number. Always make sure you know the final destination of your waste and that the destination is permitted and licensed to accept handle, store, and dispose of hazardous waste. If you have any questions, contact Dan Gwinner at (804) 698-4218

Contacts

Dan Gwinner, Office of Waste Programs, DEQ Central Office, (804) 698-4218 Kevin Greene, Waste Remediation Program Office Manager, DEQ Central Office, (804) 698-4236 Willard Keene, Waste Inspector. Southwest Regional Office, (276) 676-4847



Resources

RCRA In Focus: Dry Cleaning (available in English and Korean) www.epa.gov/epaoswer/hazwaste/id/infocus/dryclean.pdf www.epa.gov/epaoswer/hazwaste/id/infocus/k99005k.pdf

Your waste is your responsibility forever, even after it leaves your shop.

Waste Generation/Treatment Log

January 2007: have you disposed of any hazardous wastes?	Yes	No
Quantity		
Ship Date		
Shipper		
February 2007: have you disposed of any hazardous wastes?	Yes	No
Quantity		
Ship Date		
Shipper		
March 2007: have you disposed of any hazardous wastes?	Yes	No
Quantity		
Ship Date		
Shipper		
April 2007: have you disposed of any hazardous wastes?	Yes	No
Quantity		
Ship Date		
Shipper		
May 2007: have you disposed of any hazardous wastes?	Yes	No
Quantity		
Ship Date		
Shipper		
June 2007: have you disposed of any hazardous wastes?	Yes	No
Quantity		
Ship Date		
Shipper		

July 2007: have you disposed of any hazardous wastes?	Yes	No
Quantity		
Ship Date		
Shipper		
August 2007: have you disposed of any hazardous wastes?	Yes	No
Quantity		
Ship Date		
Shipper		
September 2007: have you disposed of any hazardous wastes?	Yes	No
Quantity		
Ship Date		
Shipper		
October 2007: have you disposed of any hazardous wastes?	Yes	No
Quantity		
Ship Date		
Shipper		
November 2007: have you disposed of any hazardous wastes?	Yes	No
Quantity		
Ship Date		
Shipper		
December 2007: have you disposed of any hazardous wastes?	Yes	No
Quantity		
Ship Date		
Shipper		



Future Rule Changes

In the near future, the federal EPA may be making changes to the federal regulation for dry cleaners that was effective on July 26, 2006.

The changes will affect several of the requirements listed below:

- additional emission controls for new drycleaner construction or reconstruction
- increased monitoring and record keeping
- utilization and installation of perc drycleaners co-located in residential buildings

We will notify you as soon as the changes are made, and how these changes impact your shop.

If you have any questions, please contact:

Richard Rasmussen Director DEQ Office of Small Business Assistance

PO Box 1105 Richmond, VA 23218-1105

Toll-Free: 800.592.5482 ext. 4394 (in-state only)

Telephone: 804.698.4394 Fax: 804.698.4264

Email: rgrasmussen@deq.virginia.gov